



ELITE CC

INSTRUCTIONS FOR UNPACKING AND SETTING UP

- 3 pages -

The ELITE CC is delivered packed in a wooden crate.

During all transport and transfer, the machine must be kept in its original vertical position, any variation in this position may lead to the loss of the guarantee.



Machine model	Gross dimensions (mm)	Gross weight (Kg)
ELITE CC	1970 x 1470 x 2200	675



Take special care when lifting the load: The load may not be centered!

To lift or move the load, use a forklift with blades long enough to support the machine, taking into account the width and depth of the machine for the calculation of the weights to lift.

Once the packaging has been opened, remove the fixing stops from the feet of the machine.





Use slings to move the machine.
You will find holes to attach the slings on the
sides of the machine.



Before connecting the machine, remove any protection that the machine may have to protect
the components during transport.